

Retractable Banner Stand Assembly Sheet

CAUTION


Please read before setup a Banner Stand

- The Vinyl banner (pre-installed) is fragile and must be handled with great care. Therefore, users should read the this Manual and other literature supplied with the product carefully as misuse or failure to follow the instructions may render this warranty void.
- This Banner Stand with premium banner ships pre-installed. It will be at your own risk, if taken apart to be used with other sizes or materials,
- This is not suitable for use in high traffic or confined areas. Inspect both the stand and the banner prior to use.
- This banner stand is not a toy; it is not intended or suitable for use by children

This warranty does not extend to any "Lush Banners/ Banneraholic" products which have been subject to misuse, neglect, accident, incorrect wiring or to use in violation of operating instructions furnished by us, nor extend to any units altered or repaired for warranty defect by anyone other than Lush Banners / Banneraholic.

Step One

Twist the metal feet out on the base to support the pole and banner.




Step Two

Remove the pole from the banner stand base.
Connect pole section into a long pole.
Insert pole into the hole on the base.



Step Three

Insert the fully extended pole inside the back of the base.



Step Four

Hold the top support frame of the banner and gently pull out while placing your foot on the base feet for additional support. Once out, slip the metal frame onto the plastic support on top of the pole.

